



QUICK START GUIDE

Winter Warm Battery Heated Socks

Cozy-PG-3000

Minthouz Official Website

@MinthouzOfficial

Table of contents:

- About This Guide
 - Conventions
 - More Info
 - Minthouz Smart Home Products Safety Statement
 - Safety Instructions
 - Copyright Statement
 - WEEE Directive & Product Disposal
- Chapter 1 INTRODUCTION
 - INTRODUCTION
- Chapter 2 OVERVIEW
 - OVERVIEW
 - FEATURE
 - SPECIFICATION
 - IN THE BOX
- Chapter 3 HOW TO USE
 - HOW TO USE
- Chapter 4 ATTENTION
 - CLEANING TIPS
 - ATTENTION

About This Guide

This guide is a complement to Quick Installation Guide. The Quick Installation Guide provides instructions for quick internet setup, while this guide contains details of each function and demonstrates how to configure them.

When using this guide, please notice that features of the product may vary slightly depending on the model and software version you have, and on your location, language, and internet service provider. All screenshots, images, parameters and descriptions documented in this guide are used for demonstration only.

Conventions

In this guide the following conventions are used :

Convention	Description
<u>Underlined</u>	Underlined words or phrases are hyperlinks. You can click to redirect to a website or a specific section.
Teal	The content and text that needs to be emphasized on the web page is the theme color #006666 , including menus, items, buttons, etc.
Note:	Do not ignore this type of comment, it is to remind you to better use the product to avoid the operation of the error that will cause the function to be invalid.
Tips:	Indicates important information that helps you make better use of your product.

More Info

A quick installation guide can be found in this guide.

Specifications can be found on the product page at <https://www.minthouz.com/>.

If you encounter any issues, please don't hesitate to email support@minthouz.com to provide feedbacks or contact online customer service, thank you !

Minthouz Smart Home Products Safety Statement

At Minthouz, your safety and trust drive everything we create. Our smart home solutions adhere to stringent international safety certifications (FCC/CE/RoHS) and are engineered to protect both your home and privacy.

Core Safeguards:

1. **Safe Operation:** Certified components prevent overheating, short circuits, and power surges.
2. **Privacy First:** End-to-end encryption secures personal data; we never share information without consent.
3. **Network Security:** Regular firmware updates defend against vulnerabilities; WPA3/WPA2 protocols for secure Wi-Fi integration. Physical Safety: Non-toxic materials and child-safe designs comply with global environmental and safety regulations.
4. **Family-Friendly Design:** Non-toxic, durable materials meet global safety standards for homes with children or pets.

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

Safety Instructions

Always read the safety instructions carefully.

Keep this Quick Start Guide for future reference.

Keep this equipment away from humidity.

If any of the following situation arises, get the equipment checked by a service technician:

The equipment has been exposed to moisture.

The equipment has been dropped and damaged.

The equipment has an obvious sign of breakage.

The equipment has not been working well or you cannot get it work according to Quick start Guide.

Copyright Statement

No part of this publication may be reproduced in any form by any means without the prior written permission.

Other trademarks or brand names mentioned herein are trademarks or registered trademarks of their respective companies.

WEEE Directive & Product Disposal

At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.



Usage Tips:

Install devices away from moisture, extreme heat, or humidity.

Use only Minthouz-approved accessories and power sources.

Activate two-factor authentication and strong passwords for added security.

Note: Unauthorized modifications void warranties and may compromise safety. Contact support@minthouz.com for assistance.

Smart Living, Securely Delivered.

Chapter 1 INTRODUCTION

This chapter contains the following sections:

- [INTRODUCTION](#)

INTRODUCTION


Experience customizable warmth with these innovative app-controlled heated socks! Select from four temperature settings (High, Second Highest, Medium, Low) ranging from 45–70°C (113–158°F) via the mobile app to perfectly match your comfort needs. The app also enables you to control switch, adjust temperature, set timer, and activate quick-heat mode. Powered by dual 3000mAh batteries, they deliver long-lasting warmth—up to 3.5 hours on High or 7 hours on Low—making them ideal for winter sports, hiking, or daily wear. Crafted from soft, breathable, stretchy fabric for unisex comfort and convenience, these machine-washable socks ensure you stay effortlessly warm on any cold-weather adventure.

Chapter 2 OVERVIEW

This chapter contains the following sections:

- [OVERVIEW](#)
- [FEATURE](#)
- [SPECIFICATION](#)
- [IN THE BOX](#)

OVERVIEW



1. Power Switch
2. Power cord
3. Battery port
4. Lithium battery
5. Adaptor
6. Indicator light
7. Output plug of the adaptor



- 1.Switch Symbols
- 2.Equipment Status
- 3.Temperature Switching
- 4.Temperature Range Adjustment
- 5.Gear Adjustment
- 6.Timing Button
- 7.Quick Heating Mode Button
- 8.Battery Level Display(This feature is currently being optimized. Stay tuned)

FEATURE

Through the app, you can adjust the temperature, set the timer, activate the rapid heating mode, and view the status on the mobile app.

Four temperature settings are available: Highest (65-70°C/149-158°F ; 3.5 Hours), Second highest(55-60°C/131-140°F ; 5 Hours), Medium (50-55°C/122-131°F ; 6 Hours), and Low (45°C/113°F, 7 Hours).

Equipped with two 3000mAh batteries, these socks provide up to 7 hours of warmth on the lowest setting, making them ideal for outdoor activities.

Made from soft, breathable materials, these heated socks are durable and elastic, suitable for both men and women.

The socks can be machine-washed or hand-washed, offering convenient care options.

SPECIFICATION

Size: 6-14

Color : Black+Gray

Cylinder length: 35cm/13.78 inch

Foot length: 22cm/8.66 inch

Cylinder width: 10cm/3.94 inch

Design: Heated sock pocket temperature control switch

Heating area coverage: Forefoot, instep, and toes

Weight: 230g/0.51lb

Battery: 2x 7.4V 3000mAh Battery

Highest: 65-70°C/149-158°F ; 3.5 Hours

Second highest: 55-60°C/131-140°F ; 5 Hours

Medium: 50-55°C/122-131°F ; 6 Hours

Low: 45°C/113°F ; 7 Hours

Fully Charged: 6-7 Hours

IN THE BOX

1 x A Pair of Heated Socks

2 x Lithium Battery

1 x Adapter

1 x Washing Bag

1 x Quick Start Guide

Chapter 3 HOW TO USE

This chapter contains the following sections:

- [HOW TO USE](#)

HOW TO USE



Step 1: Search for 'SAFEIER' in the App store or Googleplay and download the 'SAFEIER' App.



Step 2: Turn on the Bluetooth function of the phone.



Step 3 : Connect the device. 1.Firstly , connect the power cord to the battery. 2.Open the application and it will automatically match and connect to the device. When the following icon turns blue, indicating that the application is connected to the device, it is turned on and heating up.

Step 4 : Select your heating mode on the APP.



(1) Auto heating mode. After the device is connected to APP, the heating sock starts to heat up automatically, you can slide the gear to adjust the temperature you want.



(2) Rapid heating mode. Click "heating" at the bottom left corner of the APP, the device automatically switches to the fourth gear and heats up quickly for 2 minutes, and then turns on the automatic keep warm mode.

If you don't want to use the app, you can also control it directly using the switch on the sock.



Step 1: Fully charge the batteries with the charger before first use.

Nota: When charging, the adapter will light up red.



Step 2: Connect the battery wires inside the socks to the battery interface.



Step 3: The socks have pockets designed to hold batteries, which can be placed inside when in use.



Step 4 : Long press the button on the socks to turn on/off.


The setting can be changed by briefly pressing the power switch on the sock. The sequence is highest (red: 149-158°F) - second highest (green: 131-140°F) - medium (blue: 122-131°F) - low (yellow: 113°F).

Nota: The initial gear position is the same as the gear position when you turned it off.

Red:149-158°F




Green:131-140°F



Blue:122-131°F



Yellow:113°F



Chapter 4 ATTENTION

This chapter contains the following sections:

- [CLEANING TIPS](#) • [ATTENTION](#)

CLEANING TIPS

- 1.The water temperature should not exceed 122°F.
- 2.The battery must be removed before cleaning, and the battery connecting Wire must be sorted and put back into the battery bag (note that the battery cannot be washed with water)
- 3.Put the socks in a laundry bag and wash them in the washing machine. To minimize damage to the socks, we recommend clearing them by hand.
- 4.Turn the power cord out and dry it naturally, Do not use a high temperature iron or dry it at high temperature for dehydration.

ATTENTION

- 1.Adjust heating levels via the app (Ultra-High to Low) and lower the setting once comfortably warm; the socks remain operational even if the app disconnects, reconnecting automatically when nearby.
- 2.Avoid high-temperature/flammable environments, impacts to the battery, or disassembling it; use only the included battery and store it in a cool, dry place.
- 3.Recharge the battery every 60 days if unused frequently, and unplug it when not in use; never expose it to fire or extreme heat.
- 4.Avoid prolonged high-heat settings to prevent skin discomfort, and never wear the socks while sleeping to reduce burn risks.
- 5.Supervise users with heat insensitivity, and note this product is for personal warmth only—not medical/commercial use.
- 6.Remove batteries for storage when idle, and follow washing instructions to preserve fabric and heating functionality.

